What do I do if I am stuck in a screen or menu that I do not understand, and I want to get out?

You can always press the EXIT button to immediately return to watching TV. You can also press the **LAST** button to back up one screen at a time.