## What input source do I need to set on my TV to view programming using an HD DTA?

Please change your TV input source to HDMI and ensure the HDMI cable is properly connected to the HDMI input on your TV and HDMI output on your DTA.