How do I delete recordings?

To delete an individual show or a series, highlight it in the main My Shows list and press Clear on your remote control. If you are deleting a series that contains recordings, you will have the option to replace the recordings with links to streaming videos instead.