How do I set up my PIN?

Press MENU on the remote control. Parental Controls will be the default. Press RIGHT to Set PIN. A pop-up window appears. Here you enter a 4 digit PIN of your choice. The system will prompt you to confirm your PIN again.