How do lissue Google voice commands?

To issue a voice command, press and hold the Google microphone button, and speak naturally into the remote. Release the microphone button when you have finished speaking.