

How do I program the DTA remote control to also control my TV when I do not know the code (searching for the code)?

Last Modified on 06/24/2021 4:54 pm EDT

If your brand of TV does not respond to the remote control after trying all of the codes listed, or if your brand is not listed at all, try searching for your code.

1. Turn on your TV.
 2. Press and hold SET until the Red Light blinks twice, then release SET.
 3. Enter in 9 - 9 - 1. The Red Light will blink twice.
 4. While pointing the remote control at the TV, press and release the CH + key until the TV turns off. (Note: You may need to press CH+ numerous times). NOTE: In the search mode, the remote control will send IR codes from its library to the TV.
 5. Press SET once to lock in the code. The Red Light will blink twice.
-