

How do I change the My Shows sorting method?

Last Modified on 11/26/2024 3:21 pm EST

By default, My Shows is sorted by date, with newly added or recorded shows and movies first. You can choose to sort My Shows name (alphabetically) by pressing B on your remote control.
