

# What is QuickMode?

Last Modified on 11/26/2024 3:33 pm EST

QuickMode lets you watch a show 30% faster, while also letting you hear what everyone is saying. QuickMode is available while you're watching a recorded show, or if you're behind live TV (for instance, if you have rewound a show that is airing live). Here's how to use it:

1. While watching a recorded show, press the PLAY button on your remote to bring up the status bar.
  2. Press OK to start QuickMode.
  3. When you're finished watching QuickMode, press OK again to resume watching at normal speed.
-