

Why am I hearing no audio at all on any channel?

Last Modified on 11/27/2024 12:44 pm EST

If you are using a converter or TiVo try pressing **MUTE** on the converter or TiVo remote to be sure it is not muted. Also check to make sure the volume on the converter is not all the way down. If you are not using a converter or TiVo or you have already checked this, make sure your TV is not muted or in another audio mode such as "SAP". Check your TV volume as well. Consult your TV instruction manual or contact your local office at 877.955.SECV or [chat us](#) for further assistance.
