

How do I navigate the on-screen program guide?

Last Modified on 07/28/2021 11:52 am EDT

- Press Fast Forward to move the displayed time ahead two hours (one) page, or Rewind to move it backward.
 - Press Advance to jump 24 hours ahead, or Replay to jump 24 hours back.
 - Press OK on a shows in progress, and the channel changes to that shows. Press Record to record it.
 - Press OK on an upcoming show, and you'll see a screen with recording options. Set up your recording or press Back to go back to the guide.
-